


LED Truss Mate

User Manual



LED Truss Mate

www.showtech.com.au

LED Truss Mate

Table of Contents

- 1. Safety instructions.....3**
 - 1.1 Overhead rigging4**
 - 1.2 Power Connection6**
 - 1.3 Cleaning and Maintenance6**
- 2. Menu Navigation7**
- 3. DMX Allocation8**
- 4. Technical Specifications9**

LED Truss Mate

1. Safety Instructions

FOR SAFE AND EFFICIENT OPERATION

Be careful with heat and extreme temperature.

Avoid exposing it to direct rays of sun near a heating appliance.

Do not put it in a temperature below 41°F/5°C, or exceeding 95°F/35°C.

Keep away from humidity, water and dust.

Do not place the set in a location with a high humidity or lots of dust.

Containers with water should not be placed on the set.

Keep away from sources of hum and noise

Such as transformer motor, tuner, TV set and amplifier.

To avoid placing on un-stable location

Select a level and stable location to avoid vibration.

Do not use chemicals or volatile liquids for cleaning

Use a dry cloth to wipe off the dust, or a wet soft cloth for stubborn dirt.

NO USER SERVICABLE PARTS INSIDE.

If unit is out of service please contact your point of purchase.

If any troubles arise, remove the power plug and contact your Pro Shop representative for repair. Do not open the cabinet by yourself, it might result a danger of electric shock.

Take care with the power cable. Never pull the power cable to remove the plug from the receptacle, be sure to hold the plug.

When not using the unit for an extended period of time be sure to disconnect the plug from the receptacle.

LED Truss Mate

1.1 Overhead Rigging

This item must be built in a way that it can hold 10 times more of its weight for 1 hour without causing any damages. The installation must be secured with a secondary safety attachment. The Safety attachment has to be constructed in a way that no part of the installation can fall down. When rigging, de-rigging or servicing the fixture staying in the area below the installation place, on bridges, under high working places and other endangered areas is forbidden. Before taking the device in operation, the installation must be approved by an expert. The operator has to make sure that safety-relating and machine-technical installations are approved by a skilled person once a year.

IMPORTANT! OVERHEAD RIGGING REQUIRES EXTENSIVE EXPERIENCE.

Including (but not limited to) calculating working load limits, installation material being used, and periodic safety inspection of all installation material and the projector. If you lack these qualifications, do not attempt the installations yourself, but instead use a professional structural rigger. Improper installation can result in bodily injury and/or damage to property.

Use only professional trussing system if the item shall be lowered from the ceiling or high joists. Never let the device swing freely in a room.

CAUTION: Overhead Items may cause serious injuries when crashing down!! If there is concern about the safety then **DO NOT INSTALL** the device.

DANGER OF FIRE!

When installing the device, make sure there is no highly-flammable material (decoration articles, etc) within a distance of min. 0.5m.

LED Truss Mate

Mount the projector with the mounting bracket to your trussing system using an appropriate clamp.

For overhead use, always install a safety-rope that can hold at least 10 times the weight of the fixture. You must only use safety –ropes with quick links with screw cap. Pull the safety-rope through the hole in the mounting bracket and over the trussing system or a safe fixation spot. Insert the end in the quick link and tighten the safety screw. The maximum drop distance must never exceed 20cm

A safety rope which already held the strain of a crash or which is defective must not be used again.

DANGER TO LIFE!

Before taking into operation for the first time, the installation has to be approved by an expert.

LED Truss Mate

1.2. Power Connection

!! CAUTION !!

Never leave this device running unattended!! Every person that is involved with this item has to be qualified!!

Connect item with main plug. The voltage and frequency must exactly be the same as stated on the device. The power plug must always be inserted without force.

1.3. Cleaning and Maintenance

Please make sure that safety-relating and machine-technical installations are inspected by a skilled person once a year.

1. Make sure before installing that all screws are tightly connected and not corroded.
2. There must be no deformations on the housings, fixations and installations spots
3. No damages must be showed on the power supply cables, material fatigue and sediments

If the exterior of the unit is going to be cleaned, please use moist, lint free cloths. Never use alcohol or solvents.

The Cooling fan must be cleaned monthly and check to ensure it is free of obstructions.

To clean the interior of the device please use a vacuum cleaner or an air jet, however we recommend cleaning the lenses weekly to ensure the best output from your unit.

LED Truss Mate

2.0 Menu Navigation

No.	Menu level 1	Menu level 2	Menu level 3	Remark
1	3 - C H	d 1 d 5 1 2		DMX and Slaver DMX address (001-512) Default : 1
2	8 - C H	d 1 d 5 1 2		Default: 8-CH, d 1
3	C - -	C 1 C 2 C 3 C 4 C 5 C 6 C 7		1: R 2: G 3: B 4: GB 5: RB 6: RG 7: RGB Default: RGB
4	P - -	P 1 P 2 P 3 P 4		P1: 3Colors snap P2: 3 Colors fade P3: 7Colors snap P4: 7Colors fade Default: P1
5	S - -	S - - 1 S 1 0 0		Auto program speed Speed : 1-100 (slow - fast) Default: 100
6	S n d	S n d 1 S n d 2		Snd 1:3color Snd 2: 7color Default : Snd 1 (Operate the single mode on the Menu)
7	S e n S	u 0 u 1 0 0		000-100 Default :80
8	U - -	r 0		regulate cooler by user

LED Truss Mate

		<table border="1"> <tr><td></td><td>2</td><td>5</td><td>5</td></tr> <tr><td>g</td><td></td><td></td><td>0</td></tr> <tr><td></td><td>2</td><td>5</td><td>5</td></tr> <tr><td>b</td><td></td><td></td><td>0</td></tr> <tr><td></td><td>2</td><td>5</td><td>5</td></tr> </table>		2	5	5	g			0		2	5	5	b			0		2	5	5	<p>r: red g: green b: blue (LED dimmer0%~100%) with 000-255 Default: 255</p>
	2	5	5																				
g			0																				
	2	5	5																				
b			0																				
	2	5	5																				
9	<table border="1"> <tr><td>d</td><td>I</td><td>M</td><td></td></tr> </table>	d	I	M		<table border="1"> <tr><td></td><td>O</td><td>F</td><td>F</td></tr> <tr><td>d</td><td>I</td><td>M</td><td>1</td></tr> <tr><td>d</td><td>I</td><td>M</td><td>2</td></tr> <tr><td>d</td><td>I</td><td>M</td><td>3</td></tr> </table>		O	F	F	d	I	M	1	d	I	M	2	d	I	M	3	<p>OFF: Dimmer speed off DIM1: Dimmer speed fast DIM2: Dimmer speed middle DIM3: Dimmer speed slow Default: off</p>
d	I	M																					
	O	F	F																				
d	I	M	1																				
d	I	M	2																				
d	I	M	3																				
10	<table border="1"> <tr><td></td><td>S</td><td>E</td><td>T</td></tr> </table>		S	E	T	<table border="1"> <tr><td></td><td>O</td><td>n</td><td></td></tr> <tr><td></td><td>O</td><td>F</td><td>F</td></tr> </table>		O	n			O	F	F	<p>Infrared remote mode set Default: On</p>								
	S	E	T																				
	O	n																					
	O	F	F																				

3.0DMX Allocation

3-CH	Function	Value	Percent/Setting
1	Red	000-255	0~100%
2	Green	000-255	0~100%
3	Blue	000-255	0~100%

8-CH	Function	Value	Percent/Setting
1	Red	000-255	0~100%
2	Green	000-255	0~100%
3	Blue	000-255	0~100%
4	Color	000-015 016-255	No Function Color Macros
5	Strobe	000-015 016-255	No Function Strobe Slow to Fast
6	Speed Programs	000-255	Programs Speed Slow to Fast
		000-031	No Function
		032-063	0-100%
		064-095	100%-0
		096-127	100% -0-100%
		128-159	Colors Fade
	160-191	3Colors Snap	
	192-223	7Colors Snap	

LED Truss Mate

7	Dimmer	224-255 000-255	Sound Control 0~100%
8	Dim Mode	000-051 052-101 102-152 153-203 204-255	Menu setting dimmer mode dimmer mode off dimmer mode 1 dimmer mode 2 dimmer mode 3

4.0 Technical Specifications

Rated Power	230V/11.8W	Input Voltage AC	100V-240V 50/60Hz
Current	230V/0.097A	Output AC	Yes
Fuse	T1A 250V	Dmx Channels	3/8Channels
LED Specification	RGB 3W 140°	LED quantity	3